



Step 1. Prepare tubing by cutting end square.

Step 2. Slide ferrule and compression nut on the tubing.

Step 3. Push tubing over nipple on the fitting.

Step 4. Push ferrule and compression nut up to the fitting and tighten down.