COMMSCOPE®

**AMP® LAN® Outlet
Wallbox Kit 558251**

Instruction Sheet
408-3342
Jan 2017   Rev A

WALLBOX KIT	
PART NUMBER	**COLOR**
558251–1	Almond
558251–2	Black
558251–3	White
558251–4	Gray

Figure 1   94-447

1. INTRODUCTION

This instruction sheet provides installation procedures for the wallbox kit shown in Figure 1.

The box will accept unshielded AMP Communications Outlet, 110Connect, Universal Data Connector, Four-Position Data Connector, and Thinnet Tap, and faceplates.

2. DESCRIPTION

The wallbox kit includes a box, two No.6 X 1/2–in. long Type B mounting screws, and two 1 x 1 x 1/16–in. thick foam mounting tape.

3. MOUNTING PROCEDURES

The box may be mounted to a panel surface using screws or double-sided tape (included with the kit). Magnetic Tape 558535 (ordered separately) may be used.

The box may be used in raceways. Remove raceway plug and mount with two clips (Aw-ve-co● 11352 – purchased separately at any automotive supply store).

To obtain information on CommScope products, visit our website at
http://www.commscope.com/SupportCenter/TechnicalSupport.aspx

©2017 CommScope, Inc.
All Rights Reserved

This product is covered by one or more U.S. patents or their foreign equivalents. For patents, see www.commscope.com/ProductPatent/ProductPatent.aspx

1 of 1