


INSTALLATION INSTRUCTIONS

F4PDR Connector Fitted to FSJ4-50B Cable




READ THE INSTRUCTIONS THOROUGHLY
BEFORE ASSEMBLY



1


Do not damage inner conductor
No dañar el conductor interno
Ne pas endommager le conducteur central
Innenleiter nicht beschädigen




2

Do not damage inner conductor
No dañar el conductor interno
Ne pas endommager le conducteur central
Innenleiter nicht beschädigen

Remove adhesive
Raspar el adhesivo
Retirer l'adhésif
Klebstoff entfernen




3




4

Apply Sparingly
Aplicar Ligeramente
Appliquer un peu de Graisse au Silicone
Sparsam auftragen





5

Setting gauge (supplied)
Fijar el manometro (suministrado)
Cale de positionnement (fourni)
Abstandslehre (mitgeliefert)



Remove excess solder
Eliminar exceso de soldadura
Retirer l'excès de soudure
Überflüssiges Lötzinn entfernen

6



Andrew Corporation
Orland Park, IL., **U.S.A 60462**
Andrew Ltd.
Wokingham, Berks, **Great Britain**
Andrew Canada Inc.
Whitby, Ontario, **Canada**

Andrew Antennas
Campbellfield, Victoria, **Australia**
Andrew AKG
Zurich, **Switzerland**
Andrew GmbH
Essen, **Germany**

Antenas de Transmisión S.A. de C.V.
México, D.F. **Mexico.**
Antennes Andrew S.A.R.L.
Buc, **France**
Andrew Corporation
Tokyo, **Japan**

Andrew S.R.L.
Milan, **Italy**
Andrew España, S.A.
Madrid, **Spain.**

Printed in the E.C. September 1996